

Oven Mitt Tutorial



This oven mitt is easy to make and can be coordinated nicely with the Cooking Companion apron pattern using the fabric leftover from the completed project and a few other supplies!

Supplies Needed:

- 2 pieces of fabric measuring 9" x 11"- for mitt
*Use fabric A or B from the Cooking Companion apron pattern.
- 2 pieces of muslin or cotton fabric measuring 9" x 11"- for mitt lining
- 2 pieces of cotton batting measuring 9" x 11"- for mitt insulation
- 2 pieces of Insul~Bright Batting measuring 9" x 11"- for mitt insulation
- 2 ½" x 21" strip of contrasting fabric- for 5/8" binding on bottom of mitt
*Use fabric A or B from the Cooking Companion apron pattern.

Cutting:

1. Cut out 2 mitt pieces from main fabric, 2 mitt pieces from lining fabric, and 2 mitt pieces from Insul~Bright Batting using the pattern provided at the end of this tutorial.



Quilting Instructions:



1. Sandwich one of the batting mitt pieces between one of the lining mitt and main fabric mitt pieces (right sides face out) and pin (see above). Repeat with the other main fabric, batting, and lining fabric mitt pieces.

2. Quilt the sandwiched pieces in simple straight or diagonal lines about 1" apart, as shown.

Close-up of diagonal quilting:



Quilted mitts:



Sewing Instructions:

3. Place the two quilted pieces right sides together and pin. Stitch sides, top, and thumb with a $\frac{1}{4}$ " seam allowance, leaving bottom edge unstitched. Clip seams along rounded edges for turning, being careful not to cut into the stitching.


Here it is pinned:




And stitched:



4. Turn mitt right side out. Trim bottom edge of mitt to make even if needed.



5. Prepare binding by pressing strip in half widthwise so strip measures $1\frac{3}{4}$ " by 21".



6. Open up strip and fold one of the outer long edges in toward the center crease and press. Repeat with the other outer edge as shown below:




7. Fold along the original crease and re-press. Strip now measures $\frac{5}{8}$ " by 21".



8. Open up the binding for pinning onto the mitt. Fold beginning bias tape over and pin at one of the side seams as shown below in the top picture. Continue around the mitt pinning the raw edges of the binding to the raw edge of the mitt as shown below in the bottom picture until you are back at the beginning fold.


Fold beginning binding over like this:



Pin binding edge around mitt like this:



9. Overlap the beginning fold about an inch as shown in the pictures below. Stitch on the top fold line of the bias strip all the way around the mitt.



10. Fold the stitched bias tape to the inside of the mitt and pin, as shown below.




11. Stitch in the ditch (first picture below) making sure the tape is being stitched down on the inside of the mitt (second picture, next page).





12. Now go bake something yummy so you can show off your pretty, new oven mitt (and maybe your fun and fashionable Cooking Companion apron, too!) ☺





Oven Mitt Pattern

Cut 2 Fabric A

Cut 2 Fabric B

Cut 2 Batting

Cut 2 Insulated Batting